

# Twelve Oaks™ All-In-One Acoustic Foam

## User Manual

### Testing

Intertek Testing and Evaluation

- Sound Transmission – STC: 66 dB
- Impact Insulation – IIC: 72 dB

### Important

The subfloor must be completely dry, flat, level, clean and free of debris. Installer/owner is responsible for determining if the jobsite, subfloor, other conditions are environmentally and structurally acceptable for wood floor installation per Installation Instruction. Twelve Oaks™ declines any responsibility for any product failure resulting from or connected with subfloors, subsurface, jobsite damage or deficiencies after floors have been installed.

### Installation

Step 1: Roll out Twelve Oaks™ All-In-One Acoustic Foam with the vapor barrier film facing up.

Step 2: Properly align and join seams using the adhesion tapes provided. Ensure there is no gap along seams for any consecutive rolls

Step 3: When reached the perimeter of a room, the underlayment ends should be butted and taped

Step 4: Install flooring and any molding according to Installation Instruction or manufacturer's recommendation